



Firmware Update Method

NOTE: There are 2 parts to this firmware update.
You will need a formatted USB Thumb Drive to complete the update.
Format your thumb drive using FAT32

Part 1 - CPU Firmware Update


1. Download the firmware update onto your desktop of your PC or laptop.



2. Unzip the downloaded file and you will see the below folder on your desktop.




3. Open the unzipped folder. Format your USB thumb drive to FAT32 and copy the below file to it.



4. Insert the USB thumb drive into the USB input on the front of the radio.



5. Once inserted the below screen will be displayed. Press the **Green ✓ icon** to begin.



6. Once the update as started successfully, you will see the **Green** color bar to show the status of the update.



7. Once the update is complete you will see the below screen. Remove the USB thumb drive and turn your vehicle off and then back on. This will complete the 2nd part of the update.



Part 2 - MCU Firmware Update

There is no need to update the MCU firmware to improve the random problem.

Checking the Firmware Version

1. Press the Setting Icon on the Main Menu screen or Radio Mode screen.



2. Touch the arrow to the right of the Version text in the Settings menu as shown below.



3. If your receiver displays the below updated firmware versions, than your receiver is now up to date.

