

Limited One Year* Warranty

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

Dual Electronics Corp. Inc warrants this product to the original purchaser to be free from defects in material and workmanship for a period of one year from the date of the original purchase.

Dual Electronics Corp. Inc agrees, at our option, during the warranty period, to repair any defect in material or workmanship or to furnish an equal new, renewed, or comparable product (whichever is deemed necessary) in exchange without charges, subject to verification of the defect or malfunction and proof of the date of purchase. Subsequent replacement products are warranted for the balance of the original warranty period.

What is covered?

This warranty covers all defects in the material and workmanship in this product. The following are not covered: software, installation/removal costs, damage resulting from accident, misuse, abuse, neglect, product modification, improper installation, incorrect line voltage, unauthorized repair, or failure to follow instructions supplied with the product, or damage occurring during return shipment of the product. Specific license conditions and copyright notices for the software can be found via www.dualav.com.

Warranty Coverage

* Limited 1-year warranty. (Proof of purchase required)

- Extended Coverage: Extend your warranty from 1 year to 2 years when you register online at www.dualav.com. Registration must be completed within 60 days of the original purchase date to qualify for this extension.

What to do?

1. Before you call for service, check the troubleshooting guide in your owner's manual. A slight adjustment of any custom controls may save you a service call.
2. If you require service during the warranty period, you must carefully pack the product (preferably in the original package) and ship it by prepaid transportation with a copy of the original receipt from the retailer to an authorized service center.
3. Please describe your problem in writing and include your name, a return UPS shipping address (P.O. Box not acceptable), and a daytime phone number with your shipment.
4. For more information and for the location of the nearest authorized service center please contact us by one of the following methods
 - a. Call us toll-free at (866) 382-5476 (Monday-Friday, 9:00 am to 5:00 pm, EST)
 - b. E-mail us at cs@dualav.com

Exclusion of Certain Damages:

This warranty is exclusive and in lieu of any and all other warranties, expressed or implied, including without limitation the implied warranties of merchantability and fitness for a particular purpose and any obligation, liability, right, claim or remedy in contract or tort, whether or not arising from the company's negligence, actual or imputed. No person or representative is authorized to assume for the company any other liability in connection with the sale of this product. In no event shall the company be liable for indirect, incidental, or consequential damages.



SBX100

INSTALLATION/OWNER'S MANUAL

10" Subwoofer in Vented Enclosure
with Multiple Mounting Options



Dual Electronics Corporation Toll Free:
1-866-382-5476

Monday-Friday, 9:00 a.m. to 5:00 p.m. (EST)

www.dualav.com

©2021 Dual Electronics Corp. All rights reserved. NSA0521-V01

Printed in China



Installation

Thank you for purchasing the SBX100 10" Subwoofer in Vented Enclosure. Although Dual has attempted to make sure all of the information contained within this manual is accurate, please be aware that any part of it is subject to change without notice.




The following instructions should be used as a general guideline only. If you are unsure about performing any of the procedures listed below, please consult a professional car audio installation center.

Before installation, please follow these guidelines:

1. Be sure to carefully read and understand the instructions before attempting to install this product.
2. For safety, disconnect the negative terminal from the battery prior to beginning the installation of your amplifier.
3. Use the highest quality wire and connectors for a reliable installation and to minimize signal or power loss.
4. Use caution if you drill or cut! Be careful not to cut or drill into gas tanks, fuel lines, brake or hydraulic lines, vacuum lines or electrical wiring when working on any vehicle.
5. Never run wires underneath your vehicle. Running wires inside the vehicle provides the best protection from exhaust heat and environmental elements.
6. Avoid running wires over, near or through sharp edged surfaces. Use rubber grommets to protect any wires routed through metal.
7. When running wires from the amplifier, avoid running it near sources of high current


Connection Diagram

Strip 5/8" off the end of the wires, and connect the SBX100 to an amplifier as shown in the Connection Diagram below.



Installation Diagram

The below diagrams can be used with the dimensions listed below to provide measurements for mounting the enclosure. Design and specifications subject to change without notice.



Dimensions



Specifications

Sensitivity: 88dB

Frequency response: 25Hz-500Hz

Nominal impedance: 4 Ohm

RMS power output, 175 Watts

Peak power output: 500 Watts